

E-Z SUKKAH

Assembly Instructions

BEFORE YOU BEGIN:

1. PLEASE READ ALL THE INSTRUCTIONS BEFORE YOU BEGIN ASSEMBLY.

2. Think about where your Sukkah will be placed. It needs to stand on fairly level ground. Please keep in mind where you want the door to be. Unless you ordered a special Sukkah the door will be on the shorter side of the sukkah.

3. Unpack your Sukkah from the box. Take the time to familiarize yourself with all the parts. Please check the list to make sure you have all the parts. If you think you are missing anything please call our customer service department at (973) 778 - 5624. If the showroom is not open, please leave a detailed message on our answering machine and someone will return your call as soon as possible.

4. All directions (right or left) are always given when you are standing outside the Sukkah facing in.

ASSEMBLING YOUR E-Z SUKKAH SYSTEM:

1. Lay out the base of your Sukkah using the crossbars. ("B" bars)

For a 4' 6' 8' 10' wall use one "B" crossbar of that size length for each wall base.

For a 12' wall use two 6' "B" crossbars for each wall base.

For a 16' wall use two 8' "B" crossbars for each wall base.

2. Start with the door wall. Use the "A1" upright bars that have the closed loops on them. Insert the black tipped end of an "A1" upright bar into two "B" crossbars to form your first corner. (see diagram 1) The closed loops should be facing the length of the Sukkah. Lift the corner and tap it slightly making sure the fittings of the base and upright fit in tightly.

3. Take another "A1" upright bar with the closed loops and insert it into the other end of the shorter "B" crossbar to form the second corner.

4. If your long wall consists of two "B" crossbars insert the "C" bar (black tip down) into the two "B" crossbars, making sure the third socket on top is facing towards the inside of the Sukkah and the open loops on the bottom half are facing the outside.

5. Continue with the other two corners using the "A2" bars with the open loops. These loops should be facing the outside of the Sukkah but will not be facing the same directions.

6. Your Sukkah should now look like this. (see diagram 2)

7. Place the top "B" bars into the fittings of the "A1" bars. (The top crossbars should be identical in size to the "B" crossbars directly underneath them.) Use the rubber mallet to tap the fittings together. Those sukkahs which have "C" bars will also have one extra "B" crossbar going across on top connecting the two "C" bars.

8. Once the frame is up now you can start with the bands.

9. *Mehadrin Bands:*

Each Sukkah has four bands which go around three walls of the Sukkah. The door wall is to remain open (remember the door is always on the shorter wall). Starting with the pillar to the left of the door wall, hook a band into the top loop of the "A1" upright. (see diagram 3) Continue clockwise around the Sukkah, threading it through the loops of each upright as you come to it, ending with the "A1" upright on the right side of the door wall. After the band is hooked on pull and stretch the band so it is properly fastened to insure the Kashrus of the Sukkah. (see diagram 4) The same should be done with all four bands.

10. The canvas should now be ready to fit over the frame. Open up the canvas and find the end with the door on it. There will be two zippers (back to back) one on the canvas and one on the screening. The side with the screening faces the inside. Start from the outside of the Sukkah with the end that is closest to the door. Tie the strings on the inside part about 6 inches from the end to the corner "A1" upright which is to the right of where the door will be (when facing the Sukkah from the outside). Move counter clockwise by attaching the top Velcro over the top of the "B" crossbars and continue until the end, and tie the strings to the same upright you started with. Attach Velcro where the two sides of the Sukkah meet and then attach the bottom Velcro.

11. If you have purchased schach with your Sukkah, notched schach supports have been included. Place them over the top of the walls.

12. If you are using mat type schach, lay it perpendicular to the wooden supports and unroll it on the supports. If you are using mats, we strongly recommend that you place an additional piece of wood over the top of the mats. This wood is not included in your Sukkah system. If you are using bamboo-type schach, place it perpendicular to the supports over the top of the Sukkah.

13. Do not hang any decorations from the mats. They are not designed to hold any weight. Decorations can be hung from the wooden supports or from bamboo rod - type schach.

NOTE: If your Sukkah is placed in a large open area or an area that is subject to strong winds we suggest that you secure it using bungee cords (or other types of fastening material i.e.: string) and tightening it to a secure object in order to prevent it from shifting or blowing over.